



DIGITSOLE®
FOOTWEAR. REINVENTED.



WARM SERIES V.6/V.7

USER MANUAL



SUMMARY

USER MANUAL	1
GET STARTED.....	3
<i>Content of the Warm Series box</i>	<i>3</i>
PREPARATION OF YOUR SOLES	3
LOAD YOUR SOLES.....	3
ADJUST YOUR SOLES	4
DOWNLOADING THE DEDICATED APPLICATION	4
USE OF THE APPLICATION	4
CONFIGURATION OF THE APPLICATION	4
<i>Create your account.....</i>	<i>4</i>
<i>Privacy policy</i>	<i>5</i>
<i>Connect your soles to the application.....</i>	<i>6</i>
ADJUST THE WARM OF YOUR INSOLES	7
<i>Timer</i>	<i>8</i>
LIVE AND HISTORY	8
<i>Start a new activity.....</i>	<i>8</i>
<i>History session</i>	<i>9</i>
SETTINGS.....	9
MY PROFILE.....	9
MY INSOLES.....	10
COLLECTION	11
UNITS.....	11
LANGUAGE	12
VERSION	12
TERMS OF SERVICE AND POLICY PRIVACY	13
CONTACT US	13
LOG OUT	13
UPDATE YOUR SOLES	14
CLEAN YOUR SOLES	14
SAFETY INSTRUCTION.....	14
CONFORMITY DECLARATION.....	15



GET STARTED

Discover the first connected heated insoles for outdoor activities. They will help you warm your feet and keep up with your activity.

CONTENT OF THE WARM SERIES BOX

You will find in the box :

- 2 Warm Series V.7 insoles
- 1 user manual
- 1 cable (1 USB – 2 Micro-USB)



PREPARATION OF YOUR SOLES

The Warm Series are the first intelligent heated insoles that follow your daily activities. We recommend using the dedicated Warm Series application available on iOS and Android.

When creating your Warm Series account, the application will ask you for personal information (height, weight, gender) in order to accurately analyze your activity (distance, calories burned...)

LOAD YOUR SOLES

To load your soles:

1. Connect the charging cable to the USB port on your computer or to a USB power supply unit. We recommend using a power supply unit (Minimum current 2.0A).
2. Then connect your soles to the 2 micro USB



A full charge takes 2.5 hours. Once charged, the soles can last up to 8 hours. The battery life varies depending on the use. When the soles are fully charged, the red LED goes out.

If the battery is discharged, the battery icon on the application will show 0%. You have to recharge them.




ADJUST YOUR SOLES

To adjust the size of the soles, you can cut them by following the **dotted lines**.

BE CAREFUL not to cut beyond the dotted lines, you could damage the electrical components and the sole warranty would no longer work.

DOWNLOADING THE DEDICATED APPLICATION



The « **Warm Series** » app is free and compatible with the mobile devices that support iOS (from iPhone 4S and above) and Android (version 6.0 and above). To know which devices are compatible with the application, please check the firmware version on your phone.

Find the Warm Series app in your applications store. Search for « **WARM SERIES** » in the search tab:

- The **App Store®** for iOS devices
 - The **Play Store®** for Android devices
1. Install the App
 2. Turn on Bluetooth and localization on your smartphone.
 3. Launch the App.
 4. Create your account.

USE OF THE APPLICATION

Your soles are ready to be used, and you downloaded the application. This part will help you to use the application.

CONFIGURATION OF THE APPLICATION




CREATE YOUR ACCOUNT

To create your account :


1. Click on « Sign up».
2. Enter your personal information such as first name, last name, gender, date of birth and body measurements.



3. Enter your e-mail address.
4. Enter the password you wish to use in the "Password" and "Confirm Password" fields.
5. Click on the "Next" button.
6. Your account is now active, and you can use the application.



PRIVACY POLICY



You must accept our **privacy policy** before starting.




CONNECT YOUR SOLES TO THE APPLICATION

To connect your soles, make sure they **are fully charged**: When the red light is off, the cases are fully charged with an average battery life of 8 hours.

You must then activate the Bluetooth of your phone and launch the application. Follow the instructions given by the application and make sure your soles are unplugged so that they can be detected by your phone.

Follow the steps below:

1. The application will ask you to activate Bluetooth.
2. The application will ask you to activate location.
3. The application will ask you to access your camera. Then, you can scan the QR code located at the back of the soles.
4. The connection will be made automatically.





ADJUST THE WARM OF YOUR INSOLES



To adjust the temperature of your insoles, click "**ON**".

The remaining battery of each of the soles is displayed at the bottom of the screen.



You can then select the desired heat by moving the slider from **25 to 45°C**.

You can stop the heat by clicking on « **STOP** ».



TIMER




You can activate and deactivate the **timer** by clicking the « **ON/OFF** » button.

Once activated, the insoles will only heat for the desired period of time.

LIVE AND HISTORY

START A NEW ACTIVITY



To start a new activity session, your shoes must be associated with the application.


Click on "**GO**" to **start** a new working session. **(1)**

Click on "**STOP**" to **finish** your session and check your session's statistics. **(2)**



If during your activity, the soles disconnect from the phone, they will continue to analyze your activity. They will automatically reconnect when you press "STOP" when the activity is stopped.

HISTORY SESSION



Find automatically all your previous sessions in the **History** tab. Then select the activity you want to view at the bottom of the screen. This tab allows you to compare all your activities by month.


SETTINGS

The "**Settings**" tab allows you to know the details about the application and the soles.

MY PROFILE

On the icon "**My Profile**" you can:

- Add a profile picture,
- Modify your height,
- Modify your weight,
- Modify your feet size.




MY INSOLES



By clicking on the icon **“My insoles”**, you can delete your insoles if you want to replace them by another pair.




COLLECTION



By clicking « **Collection** », you can discover the other products of Digitsole.


UNITS



By clicking on the icon "**Units**", you can define the measurement mode on "imperial" or "metric" or temperature unit on "Celsius" or "Fahrenheit".




LANGUAGE



By clicking on the icon “**Language**”, you can change the application’s language.

VERSION




By clicking on the tab “**Version**”, you can access to information about your insoles and your phone.



TERMS OF SERVICE AND POLICY PRIVACY

By clicking on the tab “**Terms of service**” or “**Policy privacy**”, you will be automatically redirect on the dedicated web page.

CONTACT US



By clicking on “**contact us**”, you can directly access to the necessary information to contact the customer service.

LOG OUT



By clicking on the “**Log out**” tab, you can log out your profile of the application.



UPDATE YOUR SOLES

We regularly improve our products to offer you the best experience. You can receive a notification to update the application or your firmware. We recommend that you keep your insoles up to date.

The update may take a few minutes. We recommend that you fully recharge your soles before updating them.

CLEAN YOUR SOLES

Clean your Warm Series regularly. We recommend the use of wet wipes without chemicals. Never wash your soles in the washing machine.

SAFETY INSTRUCTION



Do not hit



Do not pierce or puncture



Do not twist



Do not put in the washing machine



Do not wet



Keep far from fire



Do not disassemble



Keep far from children

CONFORMITY DECLARATION

You can find the declaration of conformity for the USA (FCC), Canada (IC) and the European Union (EU) at this link: <https://www.digitsole.com/safety-instructions>